# iDock<sup>®</sup> Controls

Specification Sheet & Submittal

| Standard Features  |  |  |  |  |
|--|--|--|--|--|
| Advanced controls of loading dock equipment                      | Integrated controls of all<br>Poweramp dock equipment<br>and dock door installed |  |  |  |
| Interactive message display with system information              | 3-color light communication system   |  |  |  |
| View equipment usage and maintenance history                     | NEMA 4x enclosure  |  |  |  |
| Raised dome button design for ease of use                        | Designed and manufactured in the USA   |  |  |  |
| Fault code troubleshooting<br>display and internal LED<br>lights |  |  |  |  |

#### **General Description**


iDock Controls are technologically advanced push-button controllers and light communication used with various Poweramp loading dock equipment. iDock Controls are standard with all automatic Poweramp vehicle restraints, used with or without dock levelers.

#### Construction


iDock Controls are made with UL 4X Nonmetallic enclosures. The controls feature a modular design to reduce maintenance costs. 3-in-1 light assembly on the controller shows the state of the station and whether it is safe to enter the trailer. LCD display shows status of controls and explains fault conditions. Metal dome buttons provide positive feedback to the controls.


# Message Display

iDock Controls feature an LCD interactive message display for equipment information, system information, maintenance history, counters and settings. The operator presses the Menu button, then up and down arrows to navigate through the menu. Press Enter to advance one screen, or Menu to go back. The Message Display will also provide notices of faults, or instructions for Bypass mode or a sequence of operation.









#### **Exterior Lights**

Low profile, traffic style, red and green LED lights opposite of interior lights are standard for communication to the truck driver. A set of caution signs warns the truck driver to "Back In or Pull Out On Green Light Only".

# Warranty

iDock Controls feature a full one (1) year base warranty on all structural, mechanical and electrical parts, including freight and labor charges in accordance with Systems, LLC's Standard Warranty Policy. Systems, LLC warrants all components to be free of defects in materials and workmanship, under normal use, during the warranty period. This base warranty period begins upon the completion of installation or the sixtieth (60th) day after shipment, whichever is earlier.



# **Order Specifications**

| Equipment and Options with iDock Controls (Select all that apply) |   |   |   |  |   |  |  |
|---|---|---|---|--|---|--|--|
|   | Restraints  | Levelers  |   | Interlocking (Select one)                |   |  |  |
|   | PowerHook®<br>TPR UniLock®<br>TPR®<br>PowerStop® AAL<br>PowerStop® MAL<br>UniChock™<br>UXL<br>Light Communication Only - See OPTIONS  | <ul> <li>Pner</li> <li>Edge</li> <li>Mec</li> </ul> | raulic Pit Leveler Series<br>umatic Pit Leveler Series<br>e-of-Dock Series<br>:hanical Leveler Series<br>ical Storing (VS)  |  | None<br>(1) Restraint Engaged<br>Before Leveler Operate<br>(2) Restraint Engaged<br>Before Door Open<br>(3) Leveler Stored Before<br>Restraint Release  |  |  |
| Options (Select all that apply)                                   |   |   |   | (4) Leveler Stored Before<br>Door Closed |   |  |  |
|   | Audible Alarm<br>Emergency Stop Push Button<br>Independent Lip Control<br>Below Dock End Cycle Control<br>(Requires Independent Lip Controls)<br>Close Door to Reset Lights<br>Leveler Stored Indication Light<br>CentraPower<br>LiftMaster Logic 5.0 Maintenance System<br>Monitoring<br>Light Communication System (Select One)<br>Manual Control<br>Automatic Control with Leveler Position<br>Automatic Control with Door Position<br>3-Button Door Controls<br>Dock Light (Select One)<br>Manual Control (On/Off)<br>Automatic Control (With Door Position |   | Sensor(s)  Fluid Level Forklift Activity Vehicle Present Signal to External Equipment (Dry Contact) Restraint Engaged or in Bypass Leveler Stored Vehicle Present External Equipment Interlocking (Signal to Allow Operation) (Select One) Prevent Leveler Operation Prevent Leveler Operation Prevent Door Operation Restraint Release All Operation (All 3 of the Above) Disconnect (Select One) Rotary Fused Rotary Non-Fused Flange Fused |  | <ul> <li>(5) Door Open Before<br/>Restraint Engage</li> <li>(6) Door Closed Before<br/>Restraint Release</li> <li>Combination 1/3</li> <li>Combination 2/6</li> <li>Combination 1/2/3/4/6</li> <li>Combination 5/1/3/4</li> </ul> |  |  |
|   | <ul> <li>Automatic Control with Leveler Position</li> <li>Edge Light Controls</li> <li>Guide Light Controls (1 Light or 3 Light)</li> </ul>   |   | Flange Non-Fused Receptacle   |  | 460V / 3PH / 60HZ<br>575V / 3PH / 60HZ<br>230V / 1PH / 50HZ<br>400V / 3PH / 50HZ  |  |  |

### **Required Information**

| CUSTOMER        | BY              |
|-----------------|-----------------|
| JOB             | DATE            |
| LOCATION        | COMPANY         |
| NUMBER OF UNITS | CITY & STATE    |
| MODEL           |                 |
| SIZE            |                 |
| REPRESENTED BY  | VOLTAGE / PHASE |
| SALES REP       | DRAWING #       |

**Certified for Construction** 

Designed, Engineered, and Manufactured in the U.S.A. © 2024 Systems, LLC/Poweramp

Consistent with our policy of continuing product improvement, we reserve the right to change product specifications without notice or obligation. A continuing product improvement process is in effect at Systems, LLC. We reserve the right to make product changes without prior notice.